



BOBIL VANS INTERNAL FILL KIT

INSTALLATION INSTRUCTIONS





What comes in the box?

Thank you for purchasing this plumbing kit! In this kit you will receive everything you need to fill your internal tank from the inside of your vehicle.

Kit Contents

- 1 x 40mm Elbow with Nut
- 1m of 40mm Pipe
- 2 x 40mm Wire Clamp

Installation

1. Drill a 42-44mm hole on the top of your empty fresh water tank. Remove any plastic swarf from the inside.
2. Insert the threaded end of your 40mm elbow piece into the hole. Attach the nut and rubber gasket on the inside and tighten by hand as much as possible.
3. Attach one end of the 40mm pipe with the wire clamp to the 40mm barb.
4. Cut the 40mm pipe to the desired length. Use the 2nd wire clamp to attach to a funnel or other fill point of your choice.
5. There is no need for a breather pipe, as the inlet cap is vented.

We would love to know what you think!

Please let us know by leaving a review through the link sent through when you made your purchase, or email us at

[info@bobilvans.co.uk!](mailto:info@bobilvans.co.uk)

www.bobilvans.co.uk

@bobilvans



©2026 Bobil Vans Ltd

Registered in England. Company no: 13307438.
VAT reg no: 376 3711 79.